

Table 2: Rail assembly installation side and LNB marks

On-axis satellite	Mounting pad and feed arm side	Mark for LNB
81	A/Right	17
83	A/Right	15
85	A/Right	13
87	A/Right	11
89	A/Right	8
91	A/Right	7
93	A/Right	3
95	A/Right	2
97	NOT APPLICABLE	NOT APPLICABLE
99	NOT APPLICABLE	NOT APPLICABLE
101	NOT APPLICABLE	NOT APPLICABLE
103	NOT APPLICABLE	NOT APPLICABLE
105	NOT APPLICABLE	NOT APPLICABLE
107	B/Left	2
109	B/Left	3
111	B/Left	6
113	B/Left	8
115	B/Left	11
117	B/Left	14
119	B/Left	15
121	B/Left	17